



FASHNUL

Q1 Instructions for User

Dear user, thank you for purchasing our product. For your better experience and use of our product, please read this manual carefully before use and use this product according to the instructions.



Insert Heat Stick

Insert the special heat stick on this product through the insertion port and as shown in the picture.

Pre-heating


Press and hold the button for 2 seconds. At this time, the motor vibrates once to indicate that pre-heating has been started. At the same time, the screen lights up and starts counting down from 25. When the countdown reaches 0, there will be a vibration prompt. At this time, you can start smoking.



Smoking

Puff countdown: This product supports 16 puffs per heat stick, and the screen displays a countdown of the number of puffs, starting from 16 and ending at 0.
Smoking time count up: This product supports a smoking time of 245 seconds for a heat stick. The screen displays the smoking time, starting from 0 and ending at 245.
End of use hints: 3 puffs or 45 seconds use time left, the vibration will indicate the coming end of use.
Stop heating hints: No matter which one of the puff countdown or smoking time count up is finished, the vibration will indicate the heat stick end of use. During smoking, the 3 red dots of the small rocket show the breathing light effect.

During smoking, press and hold the button for 2 seconds to turn off heating.



Charge

Insert USB Type-C charging cable as shown in the picture below. During the charging process, the indicator light becomes a breathing effect and turns off when fully charged.

Battery status

The pentagon icon on the screen displays the current battery status.

	Battery indicator	Battery status
	1 light on	≥ 1 stick
	2 lights on	≥ 3 sticks
	≥ 3 sticks	≥ 5 sticks

	4 lights on	≥ 7 sticks
	5 lights on	≥ 9 sticks

Troubleshooting

	Project	Display phenomenon	Remark
/	Unable to insert heat stick	Unable to insert heat stick	Check whether the heat stick is matched with this product and replace it with matching one.
	Low battery alarm	The battery icon on the screen flashes 3 times and then stops.	The alarm can be cleared after charging.
	Short circuit / open circuit alarm	The alarm icon on the screen is always on, flash alternately three times.	It is not recommended to use the device again, please consult the manufacturer
!	High temperature alarm	The alarm icon is always on on the screen	It is necessary to stop using it immediately. It can be used again after the temperature of the equipment drops.
/	Can not charge	Screen is off	Replace charger or charging cable

Precautions

- Please do not disassemble or assemble this product without permission except when operating in accordance with this user guide.
- Please make sure not to allow any objects such as dust, lint or debris to enter the interior of the product as this may cause personal injury.
- Do not throw the product to avoid damage due to strong impact.
- Do not attempt to touch the heating unit under any circumstances as this may result in personal injury or damage to the product.
- Do not remove heat stick while using this product. If you need to remove them, please turn off the device immediately.
- Do not insert any objects into the heating chamber except for special heat stick.
- Do not store or use this product in an environment where flammable and explosive objects, liquids and gases are present.
- Do not store or use this product in an excessively hot or humid environment.
- Do not immerse this product in water or get it wet. If this happens accidentally during charging, please stop charging (working) immediately if safety is ensured. Please use an adapter that meets safety standards and has an output of 5V=2A to charge this product.
- This product can only be charged indoors.
- This product is suitable for special heat stick. Please do not use this product with traditional cigarettes or similar products that have not been approved by the manufacturer.
- The special heat stick for this product is for one-time use only, cannot be reused or be lit with an open flame.
- This product contains a non-replaceable battery.
- This product is a clean-free device. In case to work for a long time, it is recommended to use a cotton swab to remove any possible residue gently.
- This product uses lithium-ion batteries. When you need to discard them, please dispose of them in accordance with the local government's classification management regulations for electrical and electronic equipment and lithium-ion batteries.
- Please keep this product and components out of the reach of children.