

Dear user, thank you for purchasing our product. For your better experience and use of our product, please read this manual carefully before use and use this product according to the instructions.





Insert the special heat stick on this product through the insertion port and as shown in





۵

Puff countdown: This product supports 14 puffs per heat stick, and the screen displays a countdown of the number of puffs, starting from 14 and ending

at 0. Smoking time count up: This Smoking time count up: This product supports a smoking time of 200 seconds for a heat stick. The screen displays the smoking time, starting from 0 and ending

at 200. End of use hints: 2 puffs or 30 seconds use time left, the vibration will indicate the coming end of use.
Stop heating hints: No matter which one of the puff countdown or smoking time count up is finished, the vibration will indicate the heat stick end of use. During smoking, the 3 ed dots of the small rocket show the breathing light effect.

Option 1 for pulling out the

After smoking, rotate the stick

During smoking, press and hold the button for 2 seconds to turn

and pull it out to avoid stick

breakage and residue.

heated stick:

off heating.



Option 2 for pulling out the

①Pull up the stick cup with the stick:



@Pull out the stick from the stick compartment.

Cleaning

When there is a noticeable burning odor, clean the heating rod and the bottom of the stick

Charge Insert USB Type-C charging cable as shown in the picture below During the charging process, the indicator light becomes a breathing effect and turns off

when fully charged.

The pentagon icon on the screen displays the current battery status.

	Battery indicator	Battery status
1	1 light on	≥1 stick
/~	2 lights on	≥4 sticks
7	3 lights on	≥7 sticks

_`	4 lights on	≥10 sticks	
〈 〉	5 lights on	≥13 sticks	

Troubleshooting

	Project	Display phenomenon	Remark
/	Unable to insertheat stick	Unable to insert heat stick	Check whether the heat stick is matched with this product and replace it with matching one.
%	Low battery alarm	The battery icon on the screen flashes 3 times and then stops.	The alarm can be cleared after charging
^	Shortcircuit/ opencircuit alarm		It is not recommended to use the device again, please consult the manufacturer
!	High temperature alarm	The alarm icon is always on on the screen	It is necessary to stop using it immediately. It can be used again after the temperature of the equipment drops.
/	Cannotcharge	Screen is off	Replace charger or charging cable

Precautions
Please do not disassemble or assemble this product without permission except when operating in accordance with this user guide. Please make sure not to allow any objects such as dust, lint or debris to enter the interior of the product as this

may cause personal injury. Do not throw the product to avoid damage due to Do not throw the product oavoid damage due to group impact. To south the heating ultim dare any circumstances as this may result in personal injury or damage to the product, while using this product, if you need to premote the product of the prod

gises are present.

By a present with a product in an excessively hot or burned environment. The product in water or get it wet. If the product in water or get it wet. If you want to be not included in the product in water or get it wet. If you have been a displet that meet safety standards and Please use an adapter that meet safety standards and Please use an adapter that meet safety standards and Please use an adapter that present safety standards and the product safety to special field a first end of you. This product safe not been approved by the manufacture.

This product can be not been approved by the manufacture products that have no them approved by the manufacture. This product contains a non-replaceable battery, manufacture and the product safety in the product safe to the product safety of the product safety safe